



Barricade #2552 Prep Sheet

BARRICADE can be applied to any masonry, wood or metal surface. Surface should be properly prepared prior to application. Depending on the surface, additional steps may be required to prepare the surface for this anti-graffiti coating. Some surfaces will require fillers or base coats to insure optimal performance of BARRICADE.

After determining the surface on which BARRICADE will be applied, use the following guidelines to determine the steps necessary to apply the product.

Uncoated Concrete Block:

Step One: Apply one coat of a Block Filler

Step Two: Follow with one or two coats of a Base Coat

Step Three: The surface is now ready to apply two coats of BARRICADE

Uncoated Masonry with a Base Color:

Step One: Apply two coats of a pigmented Base Coat

Step Two: The surface is now ready to apply two coats of BARRICADE

Uncoated Masonry Clear:

Step One: Apply two coats of a Clear Masonry Sealer

Step Two: The surface is now ready to apply two coats of BARRICADE

Application Worksheet:

On what surface will Barricade be applied? _____

Do you want a color under the coating? _____

What is the square footage you will be coating? _____

Based on these answers, you will need:

Block Filler: _____ Gallons

Base Coat: _____ Gallons

Barricade: _____ Kits

Should the application require a Block Filler, a Sealers, or a Base Coat, contact Pro Chem's Technical Support Team and they will source the items needed for the application.